

$$E_a - \left(K_b + \frac{B \cdot R_a}{K_m} \right) \omega = 0$$

$$\omega = \left(\frac{K_m}{K_m K_b + B \cdot R_a} \right) E_a = K E_a$$

Transfer characteristics

