

- * Modulator Amplitude: $y(t) = \underline{x(t)} [\sin 2\pi f_c t]$
- * Modulator Fasa: $y(t) = A \sin [2\pi f_c t + \underline{x(t)}]$

NEXT LINIERISASI!

Linierisasi BUKAN mengubah Sistem Tak Linier menjadi Sistem Linier

